

HOLDER H COMPLETE 8388 / 8388-HD




HOLDER H 8388

1. 8382 Holder H
2. 8383 PU bushing
3. 9161 Beam clamp
Incl. bolts, nuts
and washers.

HOLDER H 8388-HD

1. 8382-HD Holder
2. 8383-HD PU bushing
3. 9161 Beam clamp
Incl. bolts, nuts
and washers.




SPRING LEVER ARM COMPLETE 9178



SPRING LEVER ARM

1. 9181 Lever spring
2. 9182 Spring mount, fits both L and R
3. 9186 Chain
4. 9185 Snap hook
5. 9199 Toothed washer



Holder H and Spring lever 9178 are used in most of Vendigs belt cleaners.
For larger belt-widths the bracket Holder HD and two spring levers are used.
Detailed installation instructions are included with all belt scrapers.